

Fastener/Tool Selection Guide

The following Fastener/Tool Selection Guide indicates the fastener and thread size capability of each Bollhoff tool. This chart covers products made from Steel only. For assistance in selecting tools to install aluminum or stainless steel products please contact Bollhoff Rivnut® Inc. or our Authorized Distributor.

To use the guide please do the following:

- Locate the fastener type in the top row of the chart.
- Locate the tool you are interested in along the left hand column.
- Select the intersecting data block. Each block contains the range of thread sizes that the tool will install of that particular fastener type.
- An "X" in the data block indicates that the tool has not been designed to install that fastener type.

	Rivnut® EZ Round Body Steel	Rivnut® EZ Hex Body Steel	Rivnut® PN Plusnut Steel	Rivnut® PN Pre-bulbed Plusnut Steel	Rivnut® Round Body Steel	Rivnut® Hex Body Steel	Rivstud® Steel
P 803	#6 – 5/16 M3 – M8	#8 – 5/16 M4 – M8	X	X	#6 – 1/4 M3 – M6	#10 – 1/4 M5 – M6	M5 – M8
P 330	#6 – 3/8 M3 – M10	#8 – 3/8 M4 – M10	X	X	#6 – 5/16 M3 – M8	#10 – 5/16 M5 – M8	M5 – M8
PNK	#6 – 5/16 M3 – M8	#8 – 5/16 M4 – M8	X	X	#6 – 1/4 M3 – M6	#10 – 1/4 M5 – M6	M5 – M8
EPK	#6 – 3/8 M3 – M10	#8 – 3/8 M4 – M10	X	X	#6 – 5/16 M3 – M8	#10 – 5/16 M5 – M8	M5 – M8
C 302	#6 – 3/8 M3 – M10	#8 – 3/8 M4 – M10	#6 – 3/8 M4 – M10	#10 – 3/8 M6 – M10	#6 – 5/16 M3 – M8	#10 – 5/16 M5 – M8	X
C 362	#10 – 3/8 M5 – M10	#10 – 3/8 M5 – M10	X	X	#10 – 1/2 M5 – M12	#10 – 3/8 M5 – M10	X
C 900	#10 – 3/8 M5 – M10	#10 – 3/8 M5 – M10	#10 – 3/8 M5 – M10	#10 – 3/8 M6 – M10	#10 – 1/2 M5 – M12	#10 – 3/8 M5 – M10	X
C 350*	#6 – 3/8 M4 – M10	#8 – 3/8 M4 – M10	X	X	X	X	X
ASH	#6 – 3/8 M3 – M10	#8 – 3/8 M4 – M10	X	X	#6 – 5/16 M3 – M8	#10 – 5/16 M5 – M8	M5 – M8
CFA 803	#6 – 5/16 M3 – M8	#8 – 5/16 M4 – M8			#6 – 1/4 M3 – M6	#10 – 1/4 M5 – M6	M5 – M8
BRK 01	#6 – 1/4 M3 – M6	#8 – 1/4 M4 – M6	X	X	M3 – M5	X	X
C 6000	#6 – 1/4 M4 – M6	#8 – 1/4 M4 – M6	X	X	#6 – #10 M3 – M6	#10 M5 – M6	X
C 7000	#6 – #10 M3 – M5	#8 – #10 M4 – M5	#6 – #10 M4 – M5	#10	#6 – #10 M4 – M5	#10 M5	X
BRK 10	#10 – 3/8 M5 – M10	#10 – 3/8 M5 – M10	X	X	M5 – M8	M5 – M8	X
EXP	#6 – 3/8 M3 – M10	#8 – 3/8 M4 – M10	X	#10 – 3/8 M6 – M10	X	X	X
C 1000	X	X	#6 – 1/4 M4 – M6	#10 – 1/4 M6	X	X	X
C 722	5/16 – 3/8 M8 – M10	5/16 – 3/8 M8 – M10	5/16 – 3/8 M8 – M10	5/16 – 3/8 M8 – M10	5/16 – 1/2 M8 – M12	5/16 – 3/8 M8 – M10	X
C 845	#6 – 1/4 M3 – M6	#8 – 1/4 M4 – M6	X	X	#6 – 1/4 M3 – M6	#10 – 1/4 M5 – M6	X
ES 51	1/4 – 3/8 M6 – M10	1/4 – 3/8 M6 – M10	X	X	1/4 – 5/16 M6 – M8	1/4 – 5/16 M6 – M8	X

* The C 350 tool can be used to install the Rivnut® EZ round and hex body fasteners. The fasteners MUST have a lubrication added to them to be installed with this tool. Please contact Bollhoff Rivnut® Inc. or our Authorized Distributor for details.