





C1000 Plusnut Hand Tool




Rivnut: (one-piece) tubular rivet with internal threads; blind installation provides clean threads for screw attachments

www.cardinalcomponents.com
800-236-3200


C1000 PLUSNUT HAND TOOL OPERATING INSTRUCTIONS

Wrench Type Plusnut Fastener Headers are available for Plusnuts with the following thread sizes: 4-40 through 1/4" & Metric M4 through M6. When ordering tools, always specify Plusnut thread size.

Lubricate 1/2" Jackscrew threads before use



1 Turn 1/2 nut in counterclockwise direction until stud is fully extended. Engage all threads on the stud into the Plusnut. Advance nut until fastener is tight against tool face. Insert fastener into hole.



2 Place 3/4" open end wrench on tool body and hold stationary. Using a 3/4" wrench on the 1/2 nut. Turn clockwise while holding tool perpendicular to the work.



3 Turn nut until firm resistance is felt. Several turns will be required. A box end ratchet wrench will speed up this operation. Use caution not to overupset the fastener and cause thread damage. Break nut loose with a counter-clockwise motion.



4 Remove tool from Plusnut by revolving tool body in a counter-clockwise direction.

W128 N8600 Old Orchard Rd., Menomonee Falls, WI 53051
 ISO 9001:2008 Certified · info@cardinalcomponents.com
 Visa, Mastercard & Discover Accepted · Fax: 262.252.5033